



## User's Manual SWIZA Alza Chrono

### Congratulations!


Your SWIZA Alza Chrono watch is equipped with a Swiss Made quartz movement. This movement has been meticulously designed and manufactured with the highest quality materials and components to protect it against shock, variations in temperature, water and dust.

To ensure that your watch operates with perfect precision, please carefully read and adhere to the instructions included here.

### Description of the display and control buttons

#### Display elements

Second hand  
Minute hand  
Hour hand  
Second counter  
Day of the week hand  
Minute counter  
Date





#### Control buttons

Push-button A & B  
Crown

### Setting the time

- 1 \*Pull out the crown to position III (the watch stops)
- 2 Turn the crown until you reach the correct time 8:45
- 3 \*Push the crown back into position I





#### Please note

\*In order to set the time to the exact second, 1 must be pulled out when the second hand is in position «60». Once the hour and minute hands have been set, 3 must be pushed back into position at the exact second

### Setting the date (quick mode)

- 1 Pull out the crown to position II (the watch continues to run)
- 2 Turn the crown anticlockwise until the correct date [ ] appears
- 3 Push the crown back into position I



#### Please note


During the date changing phase between approx. 9:45 PM and 12 PM, the date must be set to the date of the following day.

### Setting the date, day of the week and time


#### Example:

- Date/time on the watch: [ ] / 01:25 / MON  
- Date/time on the watch: [ ] / 20:25 / THU

- 1 Pull out the crown to position III (the watch stops)
- 2 Turn the crown anticlockwise until yesterday's day of the week WED appears




- 3 Push the crown to position II




- 4 Turn the crown until yesterday's date appears [ ]

- 5 \*Pull out the crown to position III (the watch stops)



- 6 Turn the crown anticlockwise until the correct date [ ] and day of the week THU appears

- 7 \*\*Continue to turn the crown anticlockwise until the correct time 8:35 PM appears



- 8 Push the crown back into position I

#### Please note


\*To set your watch to the exact second, please refer to the chapter entitled «setting the time»  
\*\*Please observe the AM/PM clock rhythm

### Chronograph: basic function


Start / Stop / Reset

Example:

- 1 **Start**  
Press push-button A



- 2 **Stop**  
to stop the timing, press push-button A once more and read the chronograph counter 20 min 38sec





- 3 **Zero positioning**  
Press push-button B (the chronograph hands will be reset to their positions)

### Chronograph: accumulated timing

Example:

- 1 **Start**  
start timing
- 2 **Stop**  
e.g. 15 min 5sec following 1
- 3 **Restart**  
timing is resumed
- 4 \***Stop**  
e.g. 5min 12sec following 3 = 20min 17sec



- 5 **Reset**  
The chronograph hands are returned to their zero positions



#### Please note

\*Following 4, the accumulation of the timing can be continued by pressing push-button A (Restart / Stop, Restart / Stop...)

### Chronograph: intermediate or interval timing

Example:

- 1 **Start**  
start timing
- 2 **Display interval**  
e.g. 20min 17sec (timing continues in the background)
- 3 \***Making up the measured time**  
the chronograph hands are quickly advanced to the ongoing measured time)
- 4 **Stop**  
final time is displayed
- 5 **Reset**  
the chronograph hands are returned to their zero position



#### Please note


\*Following 3, further intervals or intermediates can be displayed by pressing push-button B (display interval / make up measured time...)

### Adjusting the chronograph hands to zero position


Example:

One or several chronograph hands are not in their correct zero positions and have to be adjusted (e.g. following a battery change)

- 1 Pull out the crown to position III (all chronograph hands are in their correct or incorrect zero position)



- 2 Keep push-buttons A and B depressed simultaneously for at least 2 seconds (the second counter hand rotates by 360° - corrective mode is activated)



#### Adjusting the second counter hand

single step: 1x short  
continuous: 1x long

#### Adjusting the next hand

#### Adjusting the minute counter hand (position 6h)

single step: 1x short  
continuous: 1x long

- 3 Returning the crown to position I  
Termination of the chronograph hands adjustment (can be carried out at any time)

